

**Functions of Buttons:**

Play button: To play or pause the music, just short press the button.

Prev (Previous) button:

To turn down the volume, just press the button; Keep pressing the button to turn down the volume rapidly. To change to the previous song, just press the button 2 times in quick succession.

Next button:

To turn up the volume, just press the button; Keep pressing the button to turn up the volume rapidly. To change to the next song, just press the button 2 times in quick succession.

On/Off button: To turn the Bluetooth function on/off, just keep pressing the button.

English**How to use:**

1. Power on/off: Press the fire button 5 times in quick succession to turn the device on and off.

2. Vaping: Attach the atomizer onto the device (keep the 510 connection clean and dry). Choose the correct mode and adjust the wattage to a proper range to match the atomizer you used before using. Hold the fire button and inhale through the mouthpiece. Release the fire button and exhale.

3. Stealth function: While the device is on, simultaneously hold the fire button and the left regulatory button. This will switch the screen display on and off.

4. Key lock function: While the device is on, simultaneously press the two regulatory buttons. This will switch between Key Lock and Key Unlock function.

5. Switch the display: By pressing the left and right regulatory buttons simultaneously in shutdown state, the screen display will rotate 180 degrees. You can then view the screen from two kinds of angle through this operation.

Shift Modes: When the device is on, press the fire button 3 times in quick succession, then press the left or right regulatory button to shift among VW/Bypass/TC-Ni/TC-Ti/TC-SS/TCR Mode.

Wattage Adjustment: Under VW mode, the output wattage can be adjusted from 1W to 80W by pressing the regulatory buttons, right to increase and left to decrease.

Temperature Adjustment: Under TC (Ni, Ti, SS, TCR-M1, M2, M3) mode, simply press the left or right regulatory button to increase/decrease the temperature setting.

Bluetooth Connection:

1. Keep pressing the On/Off button, the indicator light will keep in blue and then you enter the Bluetooth mode with the warning tone of "Tok tok tok" and voice prompt of "Bluetooth Mode".

2. To search and connect WISMEC ACTIVE, please turn the Bluetooth on under your phone's settings menu. Choose "WISMEC ACTIVE" and connect the device with your phone. After connecting successfully, the device will issue a voice message of "Bluetooth Connected".

3. Keep pressing the On/Off button, the Bluetooth will disconnect, and the device will power off with the warning tone of "Tok tok tok" and the disappearance of blue indicator light.

4. The maximum receiving distance of the Bluetooth can reach 10 meters. If you disconnect the Bluetooth on purpose or the Bluetooth is off automatically because of super distance, the device will issue a voice message of "Bluetooth Disconnected" and "Bluetooth Connecting, Please Wait". If the Bluetooth is reconnected, the device will issue a message of "Bluetooth Connected Successfully".

5. When powered on, the device will power off automatically after 5 minutes under the following 3 conditions:

- (1). The device is not connected with your Bluetooth mobile phone successfully;
- (2). You did not let your mobile play music after the device is connected with your mobile phone successfully;
- (3). The music of the phone remains paused;

When powered off, the device will issue a warning tone of "Tok tok tok" and the blue indicator light will go out.

Warranty

Please consult with your WISMEC distributors for warranty policy. We are not responsible for any damage caused by user error.

This warranty is only valid for authentic WISMEC products within warranty period from date of purchase by the end user.

Warning

1. Keep out of reach of children.
2. This product is not recommended for use by young people, non-smokers, pregnant or breast-feeding women, persons who are allergic/sensitive to nicotine.

Contra-indication

1. Only have your product repaired by Wismec. Do not attempt to repair the unit by yourself as damage or personal injury may occur.
2. Do not leave the product in high temperature or damp conditions, as this may damage the product. The appropriate operation temperature is within 0°C to 45°C while charging and -10°C to 60°C while in use.
3. Keep away from water.

Possible adverse effects

1. Use of this product may cause damage to health.
2. For people with adverse reaction after using this product, it is recommended to use the juice with lower nicotine content or no nicotine.

German**Gebrauchsanleitung:**

1. Ein- / Ausschalten: Drücken Sie die Feuertaste 5 Mal kurz hintereinander, um das Gerät ein- und auszuschalten.

2. Vapen: Befestigen Sie den Verdampfer auf dem Gerät (halten Sie den 510-Anschluss sauber und trocken). Wählen Sie den verdampfen Modus und stellen Sie die Wattleistung auf einen geeigneten Bereich für den Verdampfer ein. Feuertaste drücken und durch das Mundstück inhalieren. Feuertaste loslassen und ausatmen.

3. Stealth-Funktion: Halten Sie bei eingeschaltetem Gerät gleichzeitig die Feuertaste und die linke Einstelltaste gedrückt. Dadurch wird die Bildschirmanzeige ein- und ausgeschaltet.

4. Funktion der Tastensperre: Drücken Sie bei eingeschaltetem Gerät gleichzeitig die beiden Einstelltasten. Dadurch können Sie zwischen Tastensperre und Tastenfreigabe umschalten.

5. Display drehen: Durch gleichzeitiges Drücken der linken und rechten Einstelltasten bei ausgeschaltetem Gerät wird die Bildschirmanzeige um 180 Grad gedreht. Sie können dadurch den Bildschirm aus zwei verschiedenen Blickwinkeln anzeigen.

Shift-Modi: Ist das Gerät eingeschaltet, drücken Sie dreimal kurz hintereinander die Feuertaste und dann die linke oder rechte Einstelltaste, um zwischen VW / Bypass / TC-Ni / TC-Ti / TC-SS / TCR-Modus zu wechseln.

Einstellung der Leistung in Watt: Im VW-Modus kann die Ausgangsleistung von 1W bis 80W durch die Einstelltasten eingestellt werden, rechts zum Erhöhen und Links zum Verringern.

Temperatureinstellung: Drücken Sie im Modus TC (Ni, Ti, SS, TCR-M1, M2, M3) einfach die linke oder rechte Einstelltaste, um die Temperatureinstellung zu erhöhen bzw. zu verringern.

Bluetooth Verbindung:

1. Halten Sie die Ein- / Aus-Taste gedrückt, die Kontrollleuchte leuchtet blau und Sie gelangen in den Bluetooth-Modus mit dem Hinweis "Tok Tok Tok" und der Sprachmeldung "Bluetooth Mode".

2. Um WISMEC ACTIVE zu suchen und zu verbinden, aktivieren Sie Bluetooth an Ihrem Telefon. Wählen Sie "WISMEC ACTIVE" und verbinden Sie das Gerät mit Ihrem Telefon. Nach erfolgreicher Verbindung gibt das Gerät eine Sprachnachricht "Bluetooth Connected" aus.

3. Halten Sie die Ein- / Aus-Taste gedrückt, die Bluetooth-Verbindung wird getrennt und das Gerät schaltet sich mit dem Warnton "Tok Tok Tok" aus. Die blaue Anzeigelampe erlischt.

4. Die maximale Empfangsdistanz beträgt 10 Meter. Wenn Sie die Bluetooth-Verbindung absichtlich trennen oder die Bluetooth-Verbindung aufgrund zu hoher Entfernung automatisch deaktiviert wird, gibt das Gerät eine Sprachnachricht mit dem Hinweis "Bluetooth Disconnected" und "Bluetooth-Connecting, please wait" aus. Wenn die Bluetooth-Verbindung wiederhergestellt wird, gibt das Gerät die Meldung "Bluetooth connected Successfully" aus.

5. Ist Bluetooth aktiv schaltet sich das Gerät automatisch nach 5 Minuten unter den folgenden 3 Bedingungen aus:

- (1). Das Gerät ist nicht erfolgreich mit Ihrem Bluetooth-Mobiltelefon verbunden.
- (2). Sie haben Ihr Mobiltelefon nicht auf Musik zugreifen lassen, nachdem das Gerät erfolgreich mit Ihrem Mobiltelefon verbunden wurde.
- (3). Die Musik des Telefons ist auf Pause gestellt;

Ist das Gerät ausgeschaltet, gibt das Gerät einen Warnton von "Tok Tok Tok" aus und die blaue Anzeigelampe erlischt.

Garantie Bestimmungen

Wenden Sie sich bitte bei Fragen an Ihren WISMEC Distributor. Wir sind nicht für Schäden die durch unsachgemäße Nutzung verursacht wurden verantwortlich.

Unsere Garantie ist nur gültig für original Wismec Produkte und erstreckt sich nicht auf Produkte von Drittanbietern.

Warnung

1. Das Gerät vor Kindern fernhalten.
2. Das Gerät wird nicht empfohlen für Jugendliche, Nichtraucher, Schwangere und stillende Mütter sowie Personen mit allergischen oder empfindlichen Reaktionen auf Nikotin.

Bitte Beachten

1. Lassen Sie das Gerät nur von Wismec reparieren. Versuchen Sie nicht, das Produkt selbst zu reparieren, da Schäden oder Verletzungen auftreten können.
2. Setzen Sie das Gerät nicht hohen Temperaturen oder feuchten Bedingungen aus, da es sonst zu Beeinträchtigungen kommen kann. Das Gerät sollte bei einer Temperatur von -10°C bis 60°C betrieben und zwischen 0°C bis 45°C aufgeladen werden.
3. Setzen Sie das Gerät nicht Wasser aus.

Mögliche Nebenwirkungen

1. Dieses Produkt kann sich schädlich auf Ihre Gesundheit auswirken.
2. Menschen die Nebenwirkungen nach dem Gebrauch spüren wird empfohlen, ein e-Liquid mit einem geringeren Nikotingehalt oder ohne Nikotin zu verwenden.