


CuAIO User Manual

### Manufacturer:

Jovetech (Shenzhen) Electronics Co., Ltd. Address: 1F, 9th Blvd, Changxing High Tech Industry Zone,

Shajing Town, Baoan District, ShenZhen, China. Email: service@joyetech.com (after sale)

info@joyetech.com (wholesale) Web: www.joyetech.com










Thank you for choosing Joyetech! Please read this manual carefully before use to ensure that you'll use it properly. If you require any additional information or have any questions about this product, please consult your local Joyetech store, or visit our website at www.iovetech.com

### Product introduction

Being all-in-one style, the Joyetech CuAlO starter kit skillfully integrates a built-in battery and a top-fill top airflow atomizer into one solid unit. It has a flip to open filling system and precision airflow control. Being child-proof, close the airflow first then you're able to open the top cap to refill. Having the new ProC-BF series head, it provides a more restricted draw for mouth to lung vapers and a pretty soft flavorful clouds



- ① Battery
- 2 Atomizer Base (3) Atomizer Tube
- 4 Atomizer Head
- (5) Top Cap
- 6 Mouthpiece

7 Spare 510 Mouthpiece

# Assembling:

- 1. Break down the atomizer, the atomizer head is located on the vent pipe.
- 2. Unscrew the atomizer head and drip a few drops of e-liquid into the head.
- 3. Screw it back onto the vent pipe and install the whole atomizer.
- 4. Close the airflow inlet and make sure the two marks match exactly. 5. Aim at the arrow on top, Push and pull the top cap to to reveal the filling hole.
- 6. Inject the e-liquid into the filling hole. 7. Close the top cap, adjust the airflow inlet and you're ready to go. Note: 1. Please drip a few drops of e-liquid into the atomizer head and inhale
- a few times in power-off condition (with airflow widely open) before its first use to avoid dry burn.
- 2. Please do not wash the atomizer head with water. Simply scrub it with cotton or clean dry cloth,
- 3. Please don't overfill to avoid overflown.
- 4. Please drain the e-liquid first if you want to change the atomizer head to avoid spilling.

Power on and off: Press the fire button 5 times in quick succession, the button light will flash 5 times to indicate that it is ready to use. Press the fire button 5 times in the same way, it'll be turned off.

Vaping: Hold the fire button and inhale through the mouthpiece. Release the button to exhale.

English 2

Light indication

Stay lit

Slowly flashes

Moderately flashes

Flashes in frequency

**Battery life** 

60%-100%

30%-59%

10%-29%

0-9%

Charging: Simply charge the device by connecting it with the wall adapter or computer through USB cable. When it's fully charged, the button light will go out.

# Functions:

1 English

# Short circuit protection:

- 1. Power input would be directly shut down due to electric power board and needs charging to reactivate.
- 2. Short circuit before working: button light flashes for 5 times and then power-off.
- 3. Short circuit while working: button light flashes for 3 times before short circuit (reset).

# Atomizer protection:

Press the button for 15 seconds to shut off the output, and it will flash white light for 10 times. Release the button, and the light stops flashing. Low voltage protection:

When the battery voltage is less than 3.3V, the button light flashes for 40 times and the device power-off. Press the button can not power on. Resistance examination:

- 1. When the resistance at the output end is >3.50hm, the light flashes slowly for 10 times when you press the button.
- 2, When the resistance at the output end is <0.2ohm, the light flashes quickly for 5 times, suggesting low output or potential short circuit.

# Battery display function:

The light will flash slowly or stay lit when battery quantity is high, on the contrary, the light flashes in frequency.

3 English

The battery light flashes when charging or connecting with USB, and goes out in five seconds.

# Battery using:

- 1. Please use correct charging equipment by reputable suppliers.
- 2. Please choose good batteries from reputable companies. 3. Please put the batteries on a hard surface when charging.
- 4. Please turn off the device when it is not in use.
- 5. Please use dry cloth to clean the battery and its terminals when needed.
- 6. Don't use batteries with torn casings. 7. Don't leave the charging batteries unattended.
- 8. Don't expose the battery to extreme heat, cold or direct sunlight.
- 9. Keep away from water or any liquids.

# Precautions:

- 1. Don't use the device in stormy weather or dust condition.
- 2. Connect the USB port and charger properly. Unplug the charger when the charging is completed.
- 3. Don't put the device in your pocket or handbag directly; don't mix it with coins, jewelry or other hard objects.

4. The charger and battery may heat when charging, keep away from flammable gas, liquid or other materials.

English 4

# Warning:

- 1. Keep out of reach of children.
- 2. This device is not recommended for use by people under 18 or non-smokers.
- 3. This device is not suitable for use by pregnant or breast-feeding women.
- 4. This device is not suitable for use by people who're allergic or sensitive to nicotine or those who can't use nicotine products for
- 5. This device is not suitable for use by people who has cardiovascular disease or respiratory disease.
- 6. This device is not suitable for use by people who diseases like cardiac dysfunction, high blood pressure or diabetes.

- 1. Only have your device repaired by Joyetech. Do not attempt to repair the unit by yourself as damage or personal injury may occur. 2. Do not leave the device in high temperatures or damp conditions, as this may damage the device. The appropriate operation temperature is within 0 °C to 45 °C while charging and -10 °C to 60 °C while in use.
- 3. Do not attempt to combine the device with parts of other brands of e-cigarettes. Joyetech will not take responsibility and your warranty will be void if any damage caused by this way.

### Warranty terms:

Please refer to your Joyetech product warranty card. We are not responsible for any damage caused by user error. Our warranty is not valid for products purchased from third party vendors.

Joyetech agrees to provide repair under warranty pursuant to the following terms and conditions:

- 1. This warranty provides repair free of charge for defective Joyetech brand merchandise. Warranty period is 90 days from date of purchase by the end user.
- 2. This warranty may be void as a result of any of the following conditions:
- \* Customer does not provide warranty card and original receipt of purchase.
- \* Merchandise failure or damage is caused due to improper use or unauthorized repair.
- \* Merchandise failure or damage as a result of excessive force such as dropping.
- \* Merchandise failure or damage as a result of usage outside of recommended operating conditions (see precautions in usage manual).
- \* Merchandise failure or damage caused by improper use of water or other liquid (see usage manual for operating instructions).
- \* Merchandise failure or damage due to usage with non-Joyetech components (charger, battery, and power cable).
- 3. This warranty does not cover personal items or consumable goods and attachments, including but not limited to: mouthpiece, cartridge atomizer head lanvard and leather sheath
- 4. This warranty does not cover any non-Joyetech brand products. This warranty is only valid for eligible Joyetech brand products during the warranty period of 90 days after date of purchase as indicated on proof of purchase.

Joyetech reserves the right of final decision in all warranty cases.

Joyetech may interpret and revise the content of this warranty terms.