


CuBox User Manual

Manufacturer: Joyetech (Shenzhen) Electronics Co.,Ltd.
Address: 1F, 9th Blvd, Changxing High Tech Industry Zone,
Shajing Town, Baoan District, ShenZhen, China.

Email: service@joyetech.com (after sale) info@joyetech.com (wholesale)

Web: www.joyetech.com









Notice for use

Thank you for choosing Joyetech! Please read this manual carefully before use to ensure that you'll use it properly. If you require any additional information or have any questions about this product, please consult your local Joyetech store, or visit our website at www.joyetech.com.

Product Introduction:

Being simple and compact, the CuBox features one of the most elegant starter mod with visually stunning designs available. Powered by an integrated 3000mAh battery and 2A quick charge, it will surely satisfy you on a full day long. The large and smooth fire button lets the vapers maneuver easily in either hand. The top OLED light shines as you press the button. It indicates the battery life in such an easy way that only the CuBox can bring to you.

How to Use:

Power on and off: Click the button 5 times in quick succession, the Joyetech logo light on top will flash 5 times to indicate that the device is ready to use. In the same way, it will be powered off after 5 quick clicks.

Vaping: Attach the atomizer and press the fire button and inhale. Release the fire button and exhale.

Charging: Simply charge the device by connecting it with a computer or a wall adapter via USB cable. When it's fully charged, the indicator light will go out.

Functions:

Short circuit protection:

- 1, Power input would be directly shut down due to electric power board and needs charging to reactivate.
- 2, Short circuit before working: button light flashes for 5 times and then power-off.
- 3, Short circuit while working: button light flashes for 3 times before short circuit (reset)

Atomizer protection

Press the button for 15 seconds to shut off the output, and it will flash white light for 10 times. Release the button,

and the light stops flashing.

Low voltage protection:

When the battery voltage is less than 3.3V, the button light flashes for 40 times and the device power-off. Press the button can not power on.

Resistance examination:

- 1, When the resistance at the output end is >3.5ohm, the light flashes slowly for 10 times when you press the button.
- 2, When the resistance at the output end is <0.20hm, the light flashes quickly for 3 times, meaning low output or potential short circuit.

Battery display function:

Battery life	90%-100%	70%-89%	30%-69%	10-29%	1-9%
Light indication	Five lights	Four lights	Three lights	Two lights	One light

Battery using:

- Please use correct charging equipment by reputable suppliers.
- 2. Please choose good batteries from reputable companie
- 3. Please put the batteries on a hard surface when charging.
- 4. Please turn off the device when it is not in use.
- 5. Please use dry cloth to clean the battery and its terminals when needed.
- 6. Don't use batteries with torn casings.
- 7. Don't leave the charging batteries unattended.
- 8. Don't expose the battery to extreme heat, cold or direct sunlight.
- 9. Keep away from water or any liquids.

English 2

Precautions:

1 English

- Don't use the device in stormy weather or dust condition.
- 2. Connect the USB port and charger properly. Unplug the charger when the charging is completed.
- 3. Don't put the device in your pocket or handbag directly; don't mix it with coins, jewelry or other hard objects.
- 4. The charger and battery may heat when charging, keep away from flammable gas, liquid or other materials.

Warning:

- Keep out of reach of children.
- 2. This device is not recommended for use by people under 18 or non-smokers.
- 3. This device is not suitable for use by pregnant or breast-feeding women.
- 4. This device is not suitable for use by people who're allergic or sensitive to nicotine or those who can't use nicotine products for health reasons.
- This device is not suitable for use by people who has cardiovascular disease or respiratory disease.
- 6. This device is not suitable for use by people who diseases like cardiac dysfunction, high blood pressure or diabetes.

Attention

- 1. Only have your device repaired by Joyetech. Do not attempt to repair the unit by yourself as damage or personal injury may occur.
- 2. Do not leave the device in high temperatures or damp conditions, as this may damage the device. The appropriate operation temperature is within $0 \, \mathbb{C}$ to $45 \, \mathbb{C}$ while charging and $-10 \, \mathbb{C}$ to $60 \, \mathbb{C}$ while in use.
- 3. Do not attempt to combine the device with parts of other brands of e-cigarettes. Joyetech will not take responsibility and your warranty will be void if any damage caused by this way.

Warranty terms:

Please refer to your Joyetech product warranty card. We are not responsible for any damage caused by user error. Our warranty is not valid for products purchased from third party vendors.

Joyetech agrees to provide repair under warranty pursuant to the following terms and conditions:

- 1. This warranty provides repair free of charge for defective Joyetech brand merchandise. Warranty period is 90 days from date of purchase by the end user.
- 2. This warranty may be void as a result of any of the following conditions:
- * Customer does not provide warranty card and original receipt of purchase.
- * Merchandise failure or damage is caused due to improper use or unauthorized repair.
- * Merchandise failure or damage as a result of excessive force such as dropping.
- * Merchandise failure or damage as a result of usage outside of recommended operating conditions (see precautions in usage manual).
- * Merchandise failure or damage caused by improper use of water or other liquid (see usage manual for operating instructions).

 * Merchandise failure or damage due to usage with non-Joyetech components (charger, battery, and power cable).
- 3. This warranty does not cover personal items or consumable goods and attachments, including but not limited to: mouthpiece, cartridge, atomizer head, lanyard, and leather sheath.
- 4. This warranty does not cover any non-Joyetech brand products. This warranty is only valid for eligible Joyetech brand products during the warranty period of 90 days after date of purchase as indicated on proof of purchase.

Joyetech reserves the right of final decision in all warranty cases. Joyetech may interpret and revise the content of this warranty terms.

3 English English